



* A 15 mm EPDM layer will be put on surfaces that doesn't have a fall higher than 0,6 meter. It needs to be placed on a produced bedding such as asphalt.

40-100 mm Sureplay is put on a well drained bedding sealed with rock flour. It may also be on a produced bedding.